



Clean Room/Tacky Mat

INSTALLATION INSTRUCTIONS

STEP 1. Prepare The Location.

The mat should be positioned in the entryway to assure contact with all foot or wheel-borne contaminants. To assure a secure bond, Clean and dry the area thoroughly.

STEP 2. Remove Protective Film From Bottom

Separate and remove clear, non-tabbed film from bottom to expose the adhesive layer that adheres to floor.

STEP 3. Adhere Mat To Floor

Align mat starting at one corner. If placement is correct, gradually lower the rest of the mat using even force to assure entire mat adheres to surface. While top protective layer is still on, walk on mat to apply additional pressure to be certain entire mat is in contact. Pay particular attention to edges and corners.

STEP 4. Peel Off Top Protective Film

The mat is now ready for use.

STEP 5. Watch For Particulate Build-up

When mat is visibly dirty, peel off top layer to expose a new, fresh layer.